

**B Series 16 A, 600 V AC**

Bases – standard mount				Number of contacts + ground connection				
				6		10		16
Single lever	Double lever	Housing	NPT entry (in.)		Single	Double	Lever locking type	
			Single	Double			Single	Double
		Panel base (no cover)	–	PB306**	PB310	PB110E	PB316**	PB116E
		Panel base (w/cover)	–	PB406**	PB410**	–	PB416**	–
		Box base (no cover)	1 x ½	BB406MV	BB410MV	BB010EMV	–	–
			1 x ¾	BB406MVH075	BB410MVH075	BB010MVEH075	BB416MV*	BB016EMV*
			1 x 1	BB406H100MV	BB410MVH100	BB010EH100MV	BB416H100MV	BB016EH100MV
			2 x ½	BB506MV	BB510MV	BB110EMV	–	–
			2 x ¾	BB506H075MV	BB510H075MV	BB110EH075MV	BB516MV*	BB116EMV*
		Box base (w/cover)	1 x ½	BB606MV**	BB610MV**	–	–	–
			1 x ¾	BB606H075MV**	BB610H075MV**	–	BB616MV* **	–
			1 x 1	BB606H100**	BB610H100MV**	–	BB616MVH100**	–
			2 x ½	BB706MV**	BB710MV**	–	–	–
			2 x ¾	BB706H075**	BB710H075MV**	–	BB716MV* **	–
			2 x 1	BB706H100**	BB710H100MV**	–	BB716H100MV**	–
<b>Hoods – standard mount *plastic body – “B” 3-16 Series standard hoods include gaskets; bases and special hoods do not.</b>								
		Side entry	1 x ½	SH606MV	SH610MV	SH010MV	–	–
			1 x ¾	SH606H075MV	SH610H075MV	SH010H075MV	SH616MV†	SH016MV†
			1 x 1	SH606H100MV	SH610H100MV	SH010H100MV	SH716HMV†	SH116HMV
		Top entry	1 x ½	TH806MV	TH810MV	TH210MV	–	–
			1 x ¾	TH806H075MV	TH810H075MV	TH210H075MV	TH816MV†	TH216MV†
			1 x 1	TH806H100MV	TH810H100MV	TH210H100MV	TH816H100MV	TH316HMV
<b>Coupler hoods – inline for inline, portable or special service connections. Coupler hoods mate to standard hoods only.</b>								
		Top entry	1 x ½	CH806HMV	CH810EMV	CH610E	–	–
			1 x ¾	CH806H075MV	CH810H075MV	CH610EH075MV	CH816HMV	CH616EHMV
			1 x 1	CH806H100MV	CH810H100MV	CH610EH100MV	CH916HMV	CH716EHMV
<b>Lever hoods – reverse locking lever hoods mate to post bases only.</b>								
		Side entry w/lever(s)	1 x ½	–	–	LH010EMV	–	–
			1 x ¾	–	–	LH010EH075MV	–	LH016EMV*
			1 x ¾	–	–	LH010EH100MV	–	LH116EHMV
		Top entry w/lever(s)	1 x ½	–	–	LH210EMV	–	–
			1 x ¾	–	–	LH210EH075MV	–	LH216E*
			1 x 1	–	–	LH210EH100MV	–	LH316EHMV
<b>Bases – with access cover post bases accept lever hoods only.</b>								
		Panel base + posts w/cover	–	–	–	PB210**	–	PB216**
		Box base + posts w/cover	1 x ½	–	–	BB210MV**	–	–
			1 x ¾	–	–	BB210H075MV**	–	BB216MV* **
			1 x 1	–	–	BB210H100MV**	–	BB216H100MV**
			2 x ½	–	–	BB310MV**	–	–
			2 x ¾	–	–	BB310H075MV**	–	BB316MV**
			2 x 1	–	–	BB310H100MV**	–	BB316H100MV**

\* High “H” profile may be available. Contact your ABB sales representative.

\*\* Metal “M” cover may be available. Contact your ABB sales representative.

† High “H” and Low “L” profile may be available. Contact your ABB sales representative.

BASE TO HOOD

HOOD TO COUPLER

HOOD TO BASE