

Identification	Wire cross section (mm ²)	Part number	
Han-Modular®, Removal tool, metal, for double modules, Insert the tool from the termination side between plastic frame and module and remove the module by applying slight pressure from the mating side.	1.5–6 10	09 99 000 0842	
Removal tool, for LC contact in the Han® LC module		09 99 000 0843	
Han D®, Replacement-tip, for 09 99 000 0012		09 99 000 0004	
Han D®, Removal tool, Insert tool from the mating side of the connector until it comes to a stop., By putting additional pressure on the tool the contact is unlocked and pushed out towards the termination side., When using the removal tool (...0052) the contact is unlocked by pushing the central plunger.		09 99 000 0012	
Han D®, Removal tool, Service		09 99 000 0052	
Han® C, Removal tool		09 99 000 0305 09 99 000 0381	
Han E®, Removal tool for crimp contacts, Insert the tool from the termination side until it comes to a stop., After that the contact with the attached wire can be pulled out of the isolator body.		09 99 000 0319	
Removal tool for crimp contacts, for contact in the multi module		09 99 000 0328	
Han® EasyCon, Removal tool, For assembly and disassembly of shield- ing clamps.		09 99 000 0334	
Han-Modular®, Insertion and removal tool, for D-Sub crimp contact		09 99 000 0368	