

# Load Feeders and Motor Starters for Use in the Control Cabinet

## ET 200S Motor Starters and Safety Motor Starters

### ET 200S – I/O modules

#### Terminal modules for power modules and electronic modules

#### Selection and ordering data

Version	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
<b>TM-P terminal modules for PM-E power modules</b>						
<b>TM-P15S23-A1</b> 2 × 3 terminals, termination onto AUX1 rail, AUX1 connected through to the left, screw terminals • Order unit: 1 unit • Order unit: 5 units	A A	<b>6ES7193-4CC20-0AA0</b> <b>6ES7193-4CC20-1AA0</b>		1 1	1 unit 5 units	250 250
<b>TM-P15C23-A1</b> 2 × 3 terminals, termination onto AUX1 rail, AUX1 connected through to the left, spring-type terminals • Order unit: 1 unit • Order unit: 5 units	A A	<b>6ES7193-4CC30-0AA0</b> <b>6ES7193-4CC30-1AA0</b>		1 1	1 unit 5 units	250 250
<b>TM-P15N23-A1</b> Order unit: 1 unit 2 × 3 terminals, termination onto AUX1 rail, AUX1 connected through to the left, FastConnect	A	<b>6ES7193-4CC70-0AA0</b>		1	1 unit	250
<b>TM-P15S23-A0</b> 2 × 3 terminals, termination onto AUX1 rail, AUX1 disconnected through to the left, screw terminals • Order unit: 1 unit • Order unit: 5 units	A A	<b>6ES7193-4CD20-0AA0</b> <b>6ES7193-4CD20-1AA0</b>		1 1	1 unit 5 units	250 250
<b>TM-P15C23-A0</b> 2 × 3 terminals, termination onto AUX1 rail, AUX1 disconnected through to the left, spring-type terminals • Order unit: 1 unit • Order unit: 5 units	A A	<b>6ES7193-4CD30-0AA0</b> <b>6ES7193-4CD30-1AA0</b>		1 1	1 unit 5 units	250 250
<b>TM-P15N23-A0</b> Order unit: 1 unit 2 × 3 terminals, termination onto AUX1 rail, AUX1 disconnected through to the left, FastConnect	A	<b>6ES7193-4CD70-0AA0</b>		1	1 unit	250
<b>TM-P15S22-01</b> 2 × 2 terminals, no termination onto AUX1 rail, AUX1 connected through to the left, screw terminals • Order unit: 1 unit • Order unit: 5 units	A A	<b>6ES7193-4CE00-0AA0</b> <b>6ES7193-4CE00-1AA0</b>		1 1	1 unit 5 units	250 250
<b>TM-P15C22-01</b> 2 × 2 terminals, no termination onto AUX1 rail, AUX1 connected through to the left, spring-type terminals • Order unit: 1 unit • Order unit: 5 units	A A	<b>6ES7193-4CE10-0AA0</b> <b>6ES7193-4CE10-1AA0</b>		1 1	1 unit 5 units	250 250
<b>TM-P15N22-01</b> Order unit: 1 unit 2 × 2 terminals, no termination onto AUX1 rail, AUX1 connected through to the left, FastConnect	A	<b>6ES7193-4CE60-0AA0</b>		1	1 unit	250
<b>TM-P30S44-A0</b> Order unit: 1 unit 7 × 2 terminals, termination onto AUX1 rail, AUX1 disconnected through to the left, screw terminals for PM-E F PROFIsafe	A	<b>6ES7193-4CK20-0AA0</b>		1	1 unit	241
<b>TM-P30C44-A0</b> Order unit: 1 unit 7 × 2 terminals, termination onto AUX1 rail, AUX1 disconnected through to the left, spring-type terminals for PM-E F PROFIsafe	A	<b>6ES7193-4CK30-0AA0</b>		1	1 unit	241
<b>TM-E terminal modules for electronic modules<sup>1)</sup></b>						
<b>TM-E15S24-A1</b> Order unit: 5 units 2 × 4 terminals, termination onto AUX1 rail, AUX1 connected through to the left, screw terminals	A	<b>6ES7193-4CA20-0AA0</b>		1	5 units	250
<b>TM-E15C24-A1</b> Order unit: 5 units 2 × 4 terminals, termination onto AUX1 rail, AUX1 connected through to the left, spring-type terminals	A	<b>6ES7193-4CA30-0AA0</b>		1	5 units	250
<b>TM-E15S24-01</b> Order unit: 5 units 2 × 4 terminals, no termination onto AUX1 rail, AUX1 connected through to the left, screw terminals	A	<b>6ES7193-4CB20-0AA0</b>		1	5 units	250
<b>TM-E15C24-01</b> Order unit: 5 units 2 × 4 terminals, no termination onto AUX1 rail, AUX1 connected through to the left, spring-type terminals	A	<b>6ES7193-4CB30-0AA0</b>		1	5 units	250
<b>TM-E15S23-01</b> Order unit: 5 units 2 × 3 terminals, no termination onto AUX1 rail, AUX1 connected through to the left, screw terminals	A	<b>6ES7193-4CB00-0AA0</b>		1	5 units	250

<sup>1)</sup> Observe the configuration aids for selecting suitable TM-E and TM-P.