## HMI Software

SCADA options

Design	Ordering data	Article No.
Licenses for the WebNavigator	SIMATIC WinCC WebNavigator as	
<ul> <li>The WebNavigator Client software can be installed as many times as required without the need for a license.</li> <li>Server-based licensing <ul> <li>A license is required for using the WebNavigator Server.</li> <li>Licenses are available for simultaneous access to the web server by 1, 3, 10, 30 or 100 clients.</li> </ul> </li> <li>Diagnostics Client Licensing <ul> <li>For cost-optimized access by one or a small number of WebNavigator Clients to numerous web servers (e.g. for diagnostic purposes).</li> <li>This client license provides guaranteed access to web servers at any time.</li> <li>In respect of function there is no difference compared with regular WebNavigator Clients are capable of accessing several different</li> </ul> </li> </ul>	SIMATIC WinCC WebNavigator as from Runtime Professional V14 and WinCC as from V7.4 <sup>2)</sup> Single license, license key on USB flash drive • 1 client licenses (countable) • 3 client licenses (countable) • 10 client licenses (countable) • 100 client licenses (countable) • 100 client licenses (countable) as download <sup>1)</sup> Single license, license key download, email address mandatory • 1 client licenses (countable) • 3 client licenses (countable) • 3 client licenses (countable) • 3 client licenses (countable) • 3 client licenses (countable) • 30 client licenses (countable)	6AV6362-1AB00-0BB0 6AV6362-1AD00-0BB0 6AV6362-1AF00-0BB0 6AV6362-1AJ00-0BB0 6AV6362-1AJ00-0BB0 6AV6362-1AB00-0AH0 6AV6362-1AF00-0AH0 6AV6362-1AF00-0AH0 6AV6362-1AJ00-0AH0
web servers.	100 client licenses (countable)	6AV6362-1AM00-0AH0
<i>Thin Client solutions</i> The WebNavigator can also run under Windows Server 2008 R2 SP1 or Windows Server 2012 R2 terminal services. The Windows Server 2008 R2 SP1 or Windows Server 2012 R2 operating system is required.	SIMATIC WinCC WebNavigator Diagnostics Client for WinCC V14 Runtime Professional and WinCC as from V7.4 • Standard scope of delivery • as download	6AV6362-1BA00-0BB0 6AV6362-1BA00-0AH0
<ul> <li>This makes it possible, for example, to connect SIMATIC Thin Clients to the WinCC server as visualization stations.</li> <li>For this purpose, the Windows terminal services must be installed on the PC on which the web client is installed.</li> <li>The Windows Server 2008 R2 SP1 or Windows Server 2012 R2 operating system is required.</li> <li>Up to 25 Thin Clients can be connected to one terminal server.</li> <li>Applications:</li> </ul>	WinCC WebNavigator Load Balancing for WinCC V7.4 • Load Balancing • Load Balancing Step Up <u>as download</u> RT-SW, single license, license key download, email address mandatory	6AV6362-1FA00-0BB0 6AV6362-1GA00-0BB0 6AV6362-1FA00-0AH0
Mobile devices	<ul><li>Load Balancing</li><li>Load Balancing Step Up</li></ul>	6AV6362-1GA00-0AH0
<ul><li>Handhelds</li><li>Rugged on-site visualizations</li></ul>	SIMATIC WinCC WebNavigator for Runtime Professional (WinCC V13) Single license, license key only on USB flash drive	
<ul> <li>Function</li> <li>The WinCC basic system makes setting up and configuring a WebNavigator Server very easy. WinCC process screens to be visualized via the Internet are created as usual using the graphic editor.</li> <li>To display WinCC process screens on the web client, the Microsoft Internet Explorer or browser is used independent of the supplied WinCC Web Viewer (WinCC Viewer RT).</li> <li>The operator on the web client is integrated in the central WinCC user administration and can operate and monitor the system according to the configured access rights.</li> <li>The WebNavigator supports all standard security mechanisms that can be used for applications on the Internet, e.g. routers, firewalls and proxy servers.</li> </ul>	<ul> <li>3 clients, runtime software</li> <li>10 clients</li> <li>25 clients</li> <li>50 clients</li> <li>100 clients</li> <li>150 clients</li> <li>150 clients</li> <li>Download</li> <li>Single license, license key download only, email address required for delivery</li> <li>3 clients</li> <li>10 clients</li> <li>25 clients</li> <li>50 clients</li> <li>50 clients</li> <li>100 clients</li> <li>150 clients</li> <li>100 clients</li> <li>150 clients</li> <li>100 clients</li> <li>150 clients</li> <li>100 clients</li> <li>150 clients</li> <li>150 clients</li> <li>150 clients</li> </ul>	6AV2107-0KD00-0BB0 6AV2107-0KF00-0BB0 6AV2107-0KH00-0BB0 6AV2107-0KK00-0BB0 6AV2107-0KP00-0BB0 6AV2107-0KP00-0BH0 6AV2107-0KF00-0BH0 6AV2107-0KH00-0BH0 6AV2107-0KK00-0BH0 6AV2107-0KM00-0BH0 6AV2107-0KP00-0BH0 6AV2107-0KP00-0BH0
	can be found at: http://www.siemer	

Siemens ST 80 / ST PC · 2017 3/123