

Motor Starter Protectors/Circuit Breakers


SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

3RV29 infeed system

Selection and ordering data

Type	Version	For 3RV20, 3RV23, 3RV24 motor starter protectors	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		Size	d					

Three-phase busbars with infeed



3RV2917-1A

Three-phase busbars with infeed
Incl. 3RV2917-6A end cover

- For 2 motor starter protectors with screw or spring-type terminals
- With infeed on the left S00, S0
- With infeed on the right S00, S0

2
2

3RV2917-1A
3RV2917-1E

1
1

1 unit
1 unit

41E
41E

Three-phase busbars for system expansion



3RV2917-4A

Three-phase busbars
Incl. 3RV2917-5BA00 expansion plug

- For motor starter protectors with screw or spring-type terminals
- For 2 motor starter protectors S00, S0
- For 3 motor starter protectors S00, S0

2
2

3RV2917-4A
3RV2917-4B

1
1

1 unit
1 unit

41E
41E

Plug-in connectors



3RV2917-5AA00

Plug-in connectors
To make contact with the motor starter protectors

- For spring-type terminals
- Single-unit packaging S00¹⁾³⁾ S0²⁾
- Multi-unit packaging S00¹⁾³⁾ S0²⁾

2
2
2
2

Spring-type terminals




3RV2917-5AA00
3RV2927-5AA00
3RV2917-5A
3RV2927-5A

1
1
1
1

1 unit
1 unit
10 units
10 units

41E
41E
41E
41E



3RV2917-5CA00

- For screw terminals

- Single-unit packaging S00¹⁾³⁾ S0²⁾
- Multi-unit packaging S00¹⁾³⁾ S0²⁾

2
2
2

Screw terminals



3RV2917-5CA00
3RV2927-5CA00
3RV2917-5C
3RV2927-5C

1
1
1
1

1 unit
1 unit
10 units
10 units

41E
41E
41E
41E

¹⁾ $I > 14$ A, please note derating.

²⁾ $I > 16$ A, please note derating.

³⁾ Not for 3RV1011.

Type	Version	For contactors	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		Size	d					

Contactor bases



3RV2927-7AA00

Contactor bases
For mounting direct-on-line or reversing starters

- Single-unit packaging S00¹⁾
- S00¹⁾, S0

2
2

3RV2917-7AA00
3RV2927-7AA00

1
1

1 unit
1 unit

41E
41E

¹⁾ Not for 3RV1011.