

SIMATIC PC, spare part, Mainboard without fieldbus;  
Core I5-520E; for SIMATIC Rack PC: IPC647C,  
IPC847C Notice: the mainboard can only be used after  
a device assignment "BIOS naming" in an authorized  
Repair Center

## Further information

**Information- and Downloadcenter (Catalogs, Brochures,...)**

<http://www.siemens.de/industrial-controls/catalogs>

**Industry Mall (Online ordering system)**

<https://mall.industry.siemens.com>