

KHOR LENS REMOVAL

01 place thumbs on frame bridge & index fingers on inner lens edge



02 firmly push thumbs downward while pulling the lens edges apart



03 the lenses will "pop" allowing for easy removal of lens



EDGE™
Softly Spoken

KHOR LENS INSTALLATION

01 place outside lens edge
in temple frame groove



02 align inner lens edge
with nose piece groove
while making sure lens is
in upper lens track



03 once the lens is properly
aligned in the track,
firmly press into place



EDGE™
Safety Eyewear