

# Power Contactors for Switching Motors

## Accessories for 3RT2 Contactors

General

### Options

#### Auxiliary switch: Terminal designations and identification numbers for auxiliary contacts

##### Terminal designations

The terminal designations are 2-digit, e.g. 13, 14, 21, 22:

- Tens digit: Sequence digit
  - Related terminals have the same sequence digit
- Units digit: Function digit
  - 1-2 for normally closed contacts (NC)
  - 3-4 for normally open contacts (NO)

#### Selection aid for mountable auxiliary switch blocks for power contactors and contactor relays

The auxiliary switch blocks of the 3RH29 series for mounting on the front and side can be used for power contactors as well as for contactor relays.

The possible combinations of basic unit and mounted auxiliary switch block can be found in the tables on pages 3/59 to 3/63.

Where the columns and lines intersect (blue and green in the example) you will find the identification number for the combination of basic unit (column) and auxiliary switch block (line).

Additional auxiliary switch blocks		3-pole contactors		
Order No.	Auxiliary contacts Version NO NC	3RT201 S00 10	3RT201 S00 01	3RT20. S0/S2 11
		2. 3. 4. 5.	5. 6. 7. 8.	3. 4. 5. 6.
According to EN 50012 <sup>①</sup>				
Auxiliary switches without NO contact				
3RH2911-□HA01	- 1	11	02	12
3RH2911-□HA02	- 2	12	03	13
3RH2911-□HA03	- 3	13	04	14
3RH2911-□FA04	- 4	14	-	-
Auxiliary switch with 1 NO contact				
3RH2911-□HA10	1 -	20	11	21
1 For screw terminals 2 For spring-type terminals				

<sup>①</sup> Combinations according to EN 50012, EN 50011 and IEC 60947-5-1 are in bold print. All combinations comply with EN 50005.

##### Example 1

Basic unit: 3-pole 3RT2017 motor contactor with 1 NO  
Required: 1 NO + 4 NC (Ident. No. 14)  
Result: 3RH2911-.FA04 auxiliary switch block

##### Example 2

Basic unit: 3-pole 3RT2023 motor contactor with 1 NO + 1 NC  
Required: 1 NO + 4 NC (Ident. No. 14)  
Result: Auxiliary switch block 3RH2911-.HA03

#### Identification numbers

The identification number indicates the number and type of the auxiliary contacts, e.g. 40, 31, 22, 13:

1. digit: number of normally open contacts (NO)
2. digit: number of normally closed contacts (NC)

Examples:

- 31 = 3 NO + 1 NC
- 40 = 4 NO

Type	Example 1 3RT20 motor contactor, S00 with 1 NO	Example 2 3RT20 motor contactor, S0 with 1 NO + 1 NC
Sequence digit	2. 3. 4. 5.	3. 4. 5. 6.
Type	Auxiliary switch with 4 NC, 3RH2911-.FA04	Auxiliary switch with 3 NC, 3RH2911-.HA03
Function digit	.1 .1 .1 .1 .2 .2 .2 .2	.1 .1 .1 .1 .2 .2 .2 .2
Type	3RT20 motor contactor, S00 with aux. switch block	3RT20 motor contactor, S0 with aux. switch block
Terminal designation	13 21 31 41 51 14 22 32 42 52	13 21 31 41 51 14 22 32 42 52
Result	.1 .1 .1 .1 .2 .2 .2 .2	.1 .1 .1 .1 .2 .2 .2 .2

# Power Contactors for Switching Motors

## Accessories for 3RT2 Contactors

Selection

### Auxiliary switch blocks



3RH2911-1HA22



3RH2911-2HA22

For contactors / contactor relays <sup>①</sup>	Auxiliary contacts Version		Screw terminals 	Spring-type terminals 	PS*	
	NO	NC				
Type	NO	NC	Order No.	Order No.		
<b>Auxiliary switch blocks for snapping onto the front</b>						
<b>Sizes S00 to S2<sup>②</sup></b>						
3RT2.1., 3RT2.2., 3RT2.3.	—	1		3RH2911-1HA01	3RH2911-2HA01	1 unit
3RH21, 3RH24	—	2		3RH2911-1HA02	3RH2911-2HA02	1 unit
	—	3		3RH2911-1HA03	3RH2911-2HA03	1 unit
	1	—		3RH2911-1HA10	3RH2911-2HA10	1 unit
	1	1		3RH2911-1HA11	3RH2911-2HA11	1 unit
	1	2		3RH2911-1HA12	3RH2911-2HA12	1 unit
	1	3		3RH2911-1HA13	3RH2911-2HA13	1 unit
	2	—		3RH2911-1HA20	3RH2911-2HA20	1 unit
	2	1		3RH2911-1HA21	3RH2911-2HA21	1 unit
	2	2		3RH2911-1HA22	3RH2911-2HA22	1 unit
	3	—		3RH2911-1HA30	3RH2911-2HA30	1 unit
	3	1		3RH2911-1HA31	3RH2911-2HA31	1 unit

② The 3RH29 auxiliary switches are also available with ring terminal lug connection.

The 8th digit of the article number must be changed from a "1" to a "4", e.g. 3RH2911-1HA22 → 3RH2911-4HA22.

\* You can order this quantity or a multiple thereof.  
Illustrations are approximate